





TELECOMMUNICATION KEYSTONE JACKS

KEYSTONE JACKS JKR06-UC3



Presentation




Products Description

This insert works great to add a Telecommunication connection into any room of the house office, it features dual color-coded wiring labels with both T568A and T568B wiring pattern, a rear termination field for easy termination of a jack while installed in a wall plate, surface mount boxes, and blank patch panels for a wide variety of Applications.

Features and benefits

- Available in Telecommunication, T568 A/B wiring scheme, meet or exceed TIA/EIA Cat3 requirements
- Housing : high temperature thermoplastic
- Compact jack design, 6 positions and 6 conductors
- Contact : phosphor bronze , phosphor bronze with 6 to 50 μ " gold plate
- Accept 22-26 AWG solid with a insulation diameter of 0.4-0.6 mm
- Easy to be terminated, extremely low attenuation loss and high return loss
- High reliability and superior performance
- Available in different colors

Photo



Order Information


Part number	Description	Inner box	Carton	Carton measurement	Carton weight
JKR06-UC3	Telecommunication Keystone Jack	25PCS	250PCS	L 53.5cm × W 31.3cm × H 23.4cm	3.8KG

TELECOMMUNICATION KEYSTONE JACKS



The V style IDC contacts flex not fatigue when terminated .

Compliant with Telecommunication component and channel requirement of T568A and T568B.



1500 matching recycles .

The new design allows high density solutions .

Termination caps prevent wire from dropping off .

Allow RJ45 plugs to provide high-density solutions .

Installation instructions



1 Strip back cable jacket and fan out cables based on desired wiring scheme, cut the pair separator and rip cord (if present) as close as possible to the jacket. Note: Be careful not to nick conductors.



2 View the color on the module to determine proper location of the conductors based upon preferred wiring scheme.



3 Insert each wire into the appropriate channel according to the color code on the modular's both sides.



4 Terminate wires using Linkbasic tool (P/N: TLA01) or equivalent.



5 Install dust caps by snapping into place as shown.

KEYSTONE JACKS
Copper solution products

FIBER OPTIC
SOLUTION PRODUCTS

CABINET & ENCLOSURE

TELECOMMUNICATION
SERIES

MINI LAN SOHO
SOLUTION PRODUCTS

TOOLS & TESTERS

INDEX